

### Roku

**Quick Start Guide** 





Fountaindale Public Library hopes you enjoy the streaming services provided on the Roku Ultra device. To ensure that your viewing of these services is not interrupted, please be careful not to log out of Netflix, HBO NOW or Disney<sup>+</sup> channels. Please do not remove any set channels or content. Do not enter or leave personal credit card information logged into any channels or accounts.

For any content-related concerns, please visit our website for the Collection Management Policy or request a copy upon your return of the Roku device.

Thank you, and enjoy your experience.

# What's included in your Roku kit



Roku Ultra



Power Adapter




Roku Remote



<sup>\*</sup>This device requires a Wi-Fi connection


#### **Step 1: Connect to TV**

Connect the Roku Ultra to an HDMI port on your TV, using the HDMI cable provided.



#### **Step 2: Connect to power**


Use the included power adapter to connect your Roku Ultra to a power outlet.



#### Step 3: Power on TV and select input

Use your TV remote to power on and select the HDMI input you used to connect the Roku Ultra to the TV.


Note: Depending on your TV model, there can be more than one HMDI input option.



## Roku Ultra


#### Sucess!

If everything is connected and the correct input is selected on your TV you should see the Roku Home Menu. You are now ready to connect the Roku Ultra to your Wi-Fi network.




#### Step 4: Connecting to Wi-Fi

From the Home Menu use your Roku remote to navigate to settings, then continue to arrow right to network, past set up connection, until you reach wireless. Press OK on the remote to continue




#### Step 5: Scan for Wi-Fi

At the wireless screen, press OK to scan for Wi-Fi networks, select your Wi-Fi network and press OK on the Roku remote.



#### Step 6: Wi-Fi Password

If your network is password protected, you will be prompted to enter your password. Remember passwords are case sensitive. After entering your password, press OK on the Roku remote to connect.



## Roku Remote

Use the Roku control to navigate through the various menus and applications.

#### Note:


★ The Roku remote will only work to navigate the Roku device, it will not be able to control your TV.



## Home Menu

#### **Navigating**

The Roku remote allows you to arrow left, right, up and down to navigate to the application of your choice. Press OK on the remote to access the application.



# **NETFLIX**

#### Selecting the correct profile

Select the profile that matches the Roku label found on the front or bottom of the Roku Ultra device. Press OK on the remote to access the profile.

# Who's watching? Roku 1 Roku 2 Roku 3 Roku 4 Add Profile

# **NETFLIX**

#### **Browse and Watch**

Using the remote, browse through your favorite shows and movies, then press OK on the remote to begin watching!

**Note:** Your viewing history is cleared when the Roku is returned.






#### **Browse and Watch**

HBO NOW offers thousands of titles and movies for you to choose from. Simply browse and play the show or movie of your choice.


Note: HBO NOW does not track browsing or viewing history.





#### Selecting the correct profile

Using the remote, select the profile that matches the label on the front or bottom of the Roku Ultra device.






#### **Browse and Watch**

Using the remote, browse through your favorite shows and movies, then press OK on the remote to begin watching.

**Note:** At this time Disney<sup>+</sup> is not tracking viewing history.






#### **Movies**

The content available with the Fountaindale Roku includes a collection of movies available to view through My VUDU Movies.


**Note:** Additional content may be free to view with ads.





#### **Movies**

From the VUDU home menu navigate to the top menu and select MY VUDU, then navigate to Movies. Fountaindale Roku movies are found here.





#### **Playing Movies**

Once you have selected a movie press OK on the remote. From the movie play menu make sure the WATCH option is highlighted and press OK on the remote.





#### Roku free content

The Roku channel provides additional free content as well as live TV channels. However, the premium subscription content is unavailable on the Fountaindale Roku device.



Legally Blonde 2001 | PG-13

















Roku | Options \*







#### YouTube

Browse and watch your favorite YouTube videos.

**Note:** Linked accounts will be logged out when the Roku is returned.





#### Linking

Your Fountaindale Library card gives you access to the streaming services Kanopy and hoppla. You have the option to enjoy these services on the Fountaindale Roku device. To use these services follow the instructions and link your Kanopy or hoopla account to the Roku device.

**Note:** Logged in accounts will be logged out once the Roku is returned.







#### Linking

You will need to have an active hoopla account and access to a web browser to link to the hoopla app. If you have an account, already press OK for the next step, otherwise visit the link to create an account first.

**Note:** Logged in accounts will be logged out once the Roku is returned.



#### Welcome to hoopla!

Before we begin, make sure you have a hoopla account. Don't have one? Sign up for one by visiting the link below.

https://www.hoopladigital.com

Next



#### Linking account

Log into your hoopla account on your phone or in a web browswer. Once logged in, visit hoopladigital.com/link and enter the unique code displayed on your screen. This can also be done through the settings menu on the hoopla app.

#### Link you hoopla account

Please go to https://www.hoopladigital.com/link and enter the code below to link this TV with your hoopla account.



Verifying link...



#### Check Out and Watch

Every month you will have 10 checkouts available to use on your hoopla account. Browse through thousands of titles and watch your favorites.



Borrowed

**Favorites** 

History

Movies

**Television** 

Search

Settings

Borrowed Titles


You can borrow 10 more titles this month

You don't have anything borrowed. If you did, it would be shown here.



#### Logging out


To log out of your hoopla account, navigate down to the settings menu. From the settings page, navigate over to log out and press OK on the remote to complete the logout process.



## kanopy

#### Linking

To link to Kanopy, you will need to have a Kanopy account first and you will also need access to a web browser. If you need to create an account, visit kanopy.com to link your library card.




## kanopy

#### **Linking Step 1**

Using the remote, navigate left and down to the settings menu.


**Note:** Logged in accounts will be logged out once the Roku is returned.





#### **Linking Step 2**

In the settings menu, navigate right to Login and then down to Link Device. Press OK on the Roku remote to continue.





#### **Linking Step 3**

Log into your kanopy account on your phone or in a web browswer. Once logged in, visit kanopy.com/link and enter the unique code displayed on your screen. This can also be done through the settings menu on the hoopla app.

#### Link Your Device





To link your Roku device to your Kanopy account:


- 1. Go to kanopy.com/link
- 2. Enter the code

To access Kanopy on Roku, in addition to being a member of a participating university or public library, you need to have a Kanopy account. If you don't already have one, please go to kanopy.com/user/register before linking.

## kanopy

#### Check Out and Watch


Every month, you will have 10 checkouts available to use on your Kanopy account. Browse through thousands of titles and watch your favorites.



## kanopy

#### Logging out


Using the remote, navigate left and down to the settings menu.





#### Logging out


In the settings menu, navigate right to Logout and then down to yes, log me out. Press OK on the Roku remote to continue and OK again to complete the logout process.





#### **Additional support**

For additional setup and how to use the Roku device, please visit support.roku.com.



**Explore** 

**Explore** 

**Explore** 

**Explore** 



300 W. Briarcliff Road Bolingbrook, IL 60440 630.759.2102 fountaindale.org